SUPERFINISHING

KAPP NILES

in serial production of gear boxes


Current research findings indicate that it is possible to increase the efficiency of gear transmissions without compromising the strength by reducing surface irregularities of the tooth flanks and using lowviscosity gear oil. These results are based on testing of gears which were manufactured by vibratory finishing. However, for serial producers of gearboxes, in particular, this process is not suitable in automated operations.

Within the scope of the FVA Project 654 I, tests successfully proved

that a surface finish of Rz ≤ 1 µm can be achieved by integrating a superfinishing process on conventional gear grinding machines. Nowadays, modern KAPP NILES machines provide the option of using the superfinishing technology both in profile and generating grinding processes.


profile grinding

For profile grinding, a superfinishing grinding wheel is used in addition to the conventional grinding wheel (dressable or nondressable). Both grinding tools are mounted on a tool arbor in one set-up. Once the conventional grinding process is completed, an additional grinding cycle with the superfinishing wheel achieves the required high-quality surface finish.




Due to the excellent productivity, continuous generating grinding nowadays is the preferred process for series production of gears. Thanks to the application of combined tools, consisting of a conventional as well as a superfinishing grinding tool, it is possible to achieve a surface finish of Rz 0.5 - 1 μm in a single set-up. As a rule, the additional processing time amounts to less than 50 % of the processing time in conventional grinding processes.





processing example

surface analysis after conventional generating grinding





surface analysis after additional superfinishing

1.0

	0,0 -0,5 -1,0	7	Jul W	A WA	r	Mary	0,0 -0,5 -1,0	Mikrome
	31,4 31,6 31,8 32,0 32,2 32,4 32,6 32,8 33,0 33,2 33,4 33,6 33,8 Millimeter							
Rpk	0,0801	µm R	k	0,3935	μm	Rvk	0,1162	μm
Mr1	7,88	% M	r2	90,17	%			
Rz	0,5853	μm R	ku	2,6099				
Ra	0,1077	µm R	sk	-0,2904				
Rmr(c) 91,23	% S	chnitttiefe	-0,500	μm	mr%	0,00	%
Rdq	0,61	۰						

Rauheit - R/5x0.8mm/G/300/LS-Radius

28.08.2014 08:22:42